



# TNCRN Inventory Management Quick Guide – RF Login for Local Only Connectivity

This quick guide shows how to navigate the RF (handheld) devices and steps for logging in where internet connectivity is NOT available (Local Only Connection)



Front

## Parts of the Device - Front

- Front Speaker
- LED Status Lights
- Touch Screen
- Scanner Button (blue)
- Power On/Off (yellow)
- Qwerty Keyboard
- Enter Key (blue)
- Volume Up/Down (right side, blue buttons)
- Audio Record (left side, blue buttons)



Back

## Parts of the Device - Back

- Stylus
- Back Speaker
- Hand Strap
- Battery
- Battery Release Tab



## Keyboard Close-Up



## Screen Icons Defined

	The battery is full.
	The battery is low. You need to replace or charge the battery very soon.
	The battery is charging.
	The volume is turned off. To turn the volume back on, tap this icon and choose your setting.
	The computer is connected to the network.
	The computer is not connected to the network.
	The 802.11b/g radio is connected to the wireless network.
	The computer is connected through the USB port to your desktop PC.
	The iConnect application icon. Tap it to set up Ethernet or Wireless settings.

## Start Menu

- 1 Press the yellow power button to turn on the RF Handheld device.

The unit runs Windows Mobile, so functionality is similar to a normal PC or laptop with a Windows operating system.

- 2 Tap the "Start" menu on the screen with the stylus or your finger.

- 3 Click "TelnetCE" from the Start menu.

## Login to application

After the handhelds connect to the database, you will get the login screen.


- 4 Input your user name and password to login. Press the blue "Enter" key on the keypad for "No Machine".

2



1

3



4

